




JESTER PARTS











MODELS: ECO330,ECO345,ECO360

PARTS | Jester (ECO)













1. Center Pole Cap
2. Higher Part of Center Pole (Cap + Pole)
3. Lower Part of Center Pole (Connection+ Pole)
4. Complete Center Pole
5. Higher Part of Corner Leg (Leg + Connections + Handle)
6. Higher Part of Middle Leg (Leg + Connect./Handle) 10'x20'
7. Lower Part of Leg (Leg + Foot)
8. Height Adjustment Button
9. Complete Corner Leg (Leg + Connections + Handle + Foot)
10. Complete Middle Leg (Leg + Connect./Handle) 10'x20'
11. Steel Scissors
12. Three Way Scissor Connection
13. Upper Corner Scissor Connection - 10'x20'
14. Upper Middle Scissor Connection - 10'x20'
15. Lower Corner Scissor Connection
16. Lower Middle Scissor Connection - 10'x20'
17. Lower Center Pole Scissor Connection
18. Upper Center Pole Scissor Connection
19. Foot Pin
20. Stainless Steel Bolts

PARTS | Jester (ECO)

<p>1</p> <p>EFMPT</p>  <p>Center Pole Cap</p>	<p>2</p> <p>EFMPH330</p>  <p>Higher Part of Center Pole (Cap + Pole)</p>	<p>3</p> <p>EFMPL330</p>  <p>Lower Part of Center Pole (Connection + Pole)</p>	<p>4</p> <p>EFMP330</p>  <p>Complete Center Pole</p>	<p>5</p> <p>EFFL</p>  <p>Higher Part of Corner Leg (Leg + Connections + Handle)</p>
<p>6</p> <p>EFMFH</p>  <p>Higher Part of Middle Leg (Leg + Connect./Handle)</p>	<p>7</p> <p>EFFL</p>  <p>Lower Part of Leg (Leg + Foot)</p>	<p>8</p> <p>EFHALP</p>  <p>Height Adjustment Button</p>	<p>9</p> <p>SFMPT</p>  <p>Complete Corner Leg (Leg + Connections + Handle + Foot)</p>	<p>10</p> <p>EFMF360</p>  <p>Complete Middle Leg (Leg + Connect./Handle) 10'x20'</p>

PARTS | Jester (ECO)

<p>11</p> <p>EFS330</p>  <p>Steel Scissors</p>	<p>12</p> <p>EFSC3W</p>  <p>Three Way Scissor Connection</p>	<p>13</p> <p>EFFTC</p>  <p>Upper Corner Scissor Connection - 10'x20'</p>	<p>14</p> <p>EFFMC</p>  <p>Upper Middle Scissor Connection - 10'x20'</p>	<p>15</p> <p>EFH</p>  <p>Lower Corner Scissor Connection</p>
<p>16</p> <p>EFHM</p>  <p>Lower Middle Scissor Connection - 10'x20'</p>	<p>17</p> <p>EFMPLC</p>  <p>Lower Center Pole Scissor Connection</p>	<p>18</p> <p>EFMPHC</p>  <p>Upper Center Pole Scissor Connection</p>	<p>19</p> <p>EFHAL</p>  <p>Foot Pin</p>	<p>20</p> <p>EFS</p>  <p>Stainless Steel Bolts</p>